



Taking Water Samples

- If you are testing bore water, take your sample from as close to the bore as possible
- For other water, take your sample from as close to the water source as possible
- Use a well rinsed plastic bottle for storing your sample, approx 500mls, such as a Mt Franklin Water Bottle or a 500ml Coke Bottle
- Let the bore run for approx 10-15 mins prior to taking sample
- Slow the flow and gently fill a clean bucket with the water you want tested
- Submerge your empty water bottle in the bucket under the water, until it is completely full, and then cap the bottle whilst it is still under water
- Ensure the lid is securely tightened
- CLEARLY LABEL THE BOTTLE WITH YOUR NAME AND WHERE THE SAMPLE IS TAKEN FROM - e.g John Smith - Bore
- Mail your sample, along with your payment, address details, and your phone number, to the address below. We prefer to send your result to you via email, as it ensures you will receive your results faster, so please include your email address.
- Samples must be received to us by a Thursday, in order to make the Friday morning batch, if not they will be held over until the following week's batch
- Results are usually back by the following Friday, however this may vary from time to time, depending on the Laboratory.
- Once you receive your result, contact us on 07 5500 4755, and we will comprehensively interpret your analysis for you and discuss any relevant findings.

Note: Test results are mineral and trace elements only, NOT bacterial. However, indicators within the analysis can indicate the presence of bacteria.

Mail Samples To:

Filter Systems Aust Pty Ltd
PO Box 2823
Nerang BC QLD 4211

Or call us on 07 5500 4755 for further information.